

# Size chart Jackets

## Women

Size (cm)	34	36	38	40	42	44	46	48	50
H	155	157	159	161	163	165	167	169	171
1	81	85	89	93	97	101	105	109	113
2	63	67	71	75	80	85	90	95	100
3	87	91	95	99	103	107	111	115	119
4	81,5	83	84,5	86	87,5	89	90,5	92	93,5
5	71	72	73	74	75	76	77	78	79

## Men

Size (cm)	44	46	48	50	52	54	56	58	60	62
H	175	177	179	181	183	185	187	189	191	193
1	89	93	97	101	105	109	113	117	121	125
2	74	78	82	86	90	95	100	105	110	115
3	92	96	100	104	108	112	116	120	124	128
4	88	89,5	91	92,5	94	95,5	97	98,5	100	101,5
5	78	79	80	81	82	83	84	85	86	87

## Junior


Size (cm)	150	160	170
H	152	162	172
1	75	80	90
2	67	70	73
3	80	85,5	91
4	76	82	88
5	69	73	78

## Men, short sizes

Size (cm)	21	22	23	24	25	26	27	28	29	30
H	167	169	171	173	175	177	179	181	183	185
1	89	93	97	101	105	109	113	117	121	125
2	74	78	82	86	90	95	100	105	110	115
3	92	96	100	104	108	112	116	120	124	128
4	84	85,5	87	88,5	90	91,5	93	94,5	96	97,5
5	74	75	76	77	78	79	80	81	82	83

## Men, long sizes

Size (cm)	90	94	98	102	106	110	114	118	122	126
H	183	185	187	189	191	193	195	197	199	201
1	89	93	97	101	105	109	113	117	121	125
2	74	78	82	86	90	95	100	105	110	115
3	92	96	100	104	108	112	116	120	124	128
4	91	92,5	94	95,5	97	98,5	100	101,5	103	104,5
5	83	84	85	86	87	88	89	90	91	92



1. Circumference around chest
  2. Circumference around waist
  3. Circumference around hip
  4. Measure from the neck, over the shoulder over the elbow to the knuckles
  5. Measure from the shoulder at the neck to the knuckles
- H. Height

Use this chart for Club, TL2, Smart, X.9-Pro and 600 Prone jackets